

SPECIFICATIONS

Two TYPES OF WOOD BURNING APPLIANCES are permitted:

1. **MANUFACTURED:** a manufactured, CSA-approved, non-combustible, enclosed container, designed to hold a small fire and whose size does not exceed 1 m in any direction. The appliance must be equipped with a spark arrestor with openings no larger than 12 mm x 12 mm.
2. **HAND-MADE:** a handmade, non-combustible, municipality-approved, enclosed container that may include some or all of the components of an outdoor fireplace. The appliance must be **COVERED** with a suitable steel wire mesh with openings no larger than 12 mm x 12 mm.

GUIDELINES

1. The appliance must be **INSTALLED ON A NON-COMBUSTIBLE SURFACE**. It cannot be installed on a wooden deck or any other combustible platform.
2. The appliance must **BE INSTALLED:**
 - 3 m (10 ft.) from any main building
 - 6 m (20 ft.) from a neighbouring house
 - 2 m (6 ft.) from any accessory building or structure
 - 3 m (10 ft.) from any hedge, tree, overhead wiring or any other combustible material

SAFETY MEASURES

1. **Follow the MANUFACTURER'S INSTRUCTIONS** for the safe installation and operation of the appliance.

2. The appliance shall not be used when the Department of Natural Resources has placed a **BAN ON OPEN-AIR BURNING** in the area. Call 1-866-458-8080 for burning information.
3. Only **ONE APPLIANCE** shall be used on a property **AT ONE TIME**.
4. An operable **GARDEN HOSE** or **PORTABLE FIRE EXTINGUISHER** must be readily available.
5. Always have **AN ADULT** overseeing the fire.
6. **ALWAYS EXTINGUISH** an appliance fire and never leave it unattended.

SMOKE CONTROL

Only **DRY FIREWOOD** must be burned. **DO NOT BURN** pressure-treated wood, painted wood, leaves, grass, other vegetation, any plastic material, food or any material that produces an unreasonable amount of smoke or other respiratory irritants.

The appliance shall **NOT BE USED IF IT CAUSES UNDOE HARM TO NEIGHBOURS**. Many people suffer from allergies and respiratory problems. It is important to keep smoke at a minimum. Smoke enters homes through air exchangers and open windows. **BE COURTEOUS** while using your outdoor wood-burning appliance.

INFRACTIONS

People who do not follow outdoor wood-burning appliance rules are subject to a fine of up to \$500 under bylaw S-5 – A Bylaw Respecting Fire Prevention for the City of Campbellton.

For more information, please call 789-2711.

Rules and Regulations for Outdoor Wood-Burning Appliances



www.campbellton.org